

# PCFILT comprehensive passive filter design and evaluation

---

## \*\* General \*\*

Overview	
Dedication - overview - startup .....	1-1
Main menu - New design menu .....	1-4
System value notation .....	1-6
Utilities menu .....	1-7
PCFILT to Touchstone(R) file converter .....	1-8
Resistor pads .....	1-9
Sample session (tutorial) .....	1-10
Choosing common bandpass filter types .....	1-14
Setting and Changing design parameters	
Design parameters menu .....	2-1
Parameters identified .....	2-2
Estimation of required parameters .....	2-5
Lowpass reference values	
Reference values menu .....	3-1
External normalized "G" or "k" and "q" values .....	3-1
Using external values from disk file .....	3-3
Making external values into disk files .....	3-4
Reference value pole placer .....	3-5
Standard library responses (Bessel, Gaussian etc.) .....	3-8
Documenting designs	
Data review and hard copy menu .....	4-1
Printing schematic diagrams and graphics .....	4-2
Displaying analysis data .....	4-3
Interfacing with other software	
Predefined network code numbers .....	5-1
Sample ".DZN" file.....	5-5
Reading ".DZN" file format in BASIC and "C".....	5-7

## \*\* Filter Design \*\*

Direct scaled bandpass filter modules	
Basic direct scaled (lowpass to bandpass) .....	6-1
Forced value (transformed) .....	6-2
Direct scaled filters with "notches" .....	6-5
Minimum component (transformed) .....	6-9
Narrow band approximations (reactance coupled sections)	
General information .....	7-1
L, C, X, Z, and D couplings (defined) .....	7-2
Design modes (Equal L - Equal C etc.) .....	7-3
The inter-network "dual" (the D coupling) .....	7-4
Norton / narrow band combination (the X coupling) .....	7-5
Narrow band filters with "notch" sections .....	7-7
An "extra notch" (the Z coupling) .....	7-8
L-C "tubular" filter .....	7-9
Equal shunt L-C tubular .....	7-10
Mechanical "coaxial" tubular .....	7-11
Miscellaneous bandpass filters	
Iterated narrow bandwidth elliptic function .....	8-1
Wide bandwidth linear phase .....	8-1
Zig-Zag minimum inductor even order .....	8-3
Automatic programmable impedance matcher	
Overview and matcher status window .....	9-1

Parallel input matching options .....	9-3
Series input matching options .....	9-5
Conventional bandpass pole placer and Synthesizer	
Pole and zero finder dialog box .....	10-1
Adjusting extreme zeros .....	10-2
The mask and specification margin display .....	10-2
Automatic placer control buttons .....	10-3
Selecting finite zero removal sequence .....	10-4
Synthesis process .....	10-5
Determining the extreme zero count .....	10-5
Finite zeros and synthesis rules and procedures .....	10-6
Redundant elements, minimum component equivalent .....	10-7
Transforming designs .....	10-8
Bandpass pole placer design examples	
Procedure for a typical filter from mask specifications ...	11-1
A wide bandwidth (67%) - all pole (tubular) .....	11-6
Equalizer design	
Amplitude equalizer options .....	12-1
Delay equalizer options .....	12-2
Designing to delay data .....	12-2
The marker menu .....	12-3
The main menu .....	12-4
Equalizer manual "tune" mode .....	12-6
L-C Notch filters	
Direct scaled notch .....	13-1
Narrow bandwidth (Geffe transformed) notch .....	13-1
Hybrid cable isolated notch .....	13-3
Elliptic function narrow band notch .....	13-6
Transmission line bandpass filters	
Comblines and Interdigital input matching .....	14-1
Resonator length and capacitive loading .....	14-2
Example combline filter .....	14-3
Resonator spacing .....	14-4
<- Error level .....	14-7
Wide bandwidth direct connected .....	14-8
Dielectric resonator filters .....	14-8
Eliminating the section capacitors .....	14-10
Transmission line Notch filters	
Narrow band .....	15-1
General stub and Kuroda transformed notch .....	15-2
Resonator types and configurations .....	15-3
Line / Stub association convention .....	15-5
Example N=2 Spur line and dimensions .....	15-5
** Network Evaluation **	
Network analysis	
Main analysis dialog box .....	16-1
Display modes .....	16-1
Group delay modes .....	16-1
Impedance AT a point .....	16-2
Transmission line Q vs dB / unit length .....	16-2
Power distribution analysis	
Control window .....	17-1
Maximum value survey and display .....	17-4
Lumped component example of use .....	17-4
Concentrating on individual components .....	17-6

reactive loads - VSWR .....	17-7
Complex branches .....	17-8
Voltages at resonators .....	17-10
Graphic display of analysis	
Overview and plot menu .....	18-1
Plot menu .....	18-2
Bottom line captions .....	18-4
Fixed static frequency markers & range limit transferring .	18-5
Temporary scale factors .....	18-6
Custom logo .....	18-7
Fourier impulse response	
Control menu .....	19-1
Display time "window" .....	19-3
Display menu .....	19-3
Marker use .....	19-4
Multiplexer design and channel joining	
Joining 2 port combline diplexer with common resonator ....	20-1
Use of forced " <-- Common" branch .....	20-4
High - Lowpass contiguous L-C diplexer .....	20-6
** Network Optimization and transformations **	
Manual circuit editor	
Editor entry .....	21-1
Editing commands and menu selection .....	21-1
Branch numbers .....	21-2
Schematic diagram symbols .....	21-3
Understanding stub schematic symbols .....	21-6
Editing commands explained	
Change .....	21-8
Combine .....	21-8
Copy .....	21-9
Elliptic distributed cap. absorber Cp .....	21-9
Delete and Coupled Triplet .....	21-10
Dipole equivalents (3 and 4 element) .....	21-11
Equal value L-C, Exit, Force branch .....	21-13
Help screens and Interchange branches .....	21-15
Insert new components .....	21-16
Elliptic minimum spread iteration .....	21-17
"j" and "k" impedance inverter .....	21-19
Kuroda identities .....	21-21
Moving branches .....	21-22
Norton transform identities .....	21-24
OOps, Un-Do mistakes and Negative values .....	21-26
Program stub generator from editor .....	21-26
"Pi" to "Delta" conversion .....	21-26
Preset branch ratio .....	21-27
Recall saved network .....	21-27
Reverse network source-for-termination .....	21-27
Scaling frequency, impedance, Invert, Dual .....	21-28
Split branches into two .....	21-28
Stub / L-C equivalents .....	21-28
Saving networks .....	21-29
L-C parts value spread .....	21-29
Optimization	
Overview and entry .....	22-1
The control menu and command line .....	22-2
Set-up memory .....	22-3
Frequency ranges .....	22-4

Manual tune mode .....	22-6
Operation hints .....	22-7
Error warnings .....	22-8
L-C —> Stub equivalents	
L-C / stub equivalent menu .....	23-1
Programming .....	23-2
Constants .....	23-3
Operation .....	23-3
Microstrip dimensions .....	23-4
Dos version differences	Appendix A
Example of use of Kuroda identities	Appendix B
Coupled Triplets	Appendix D